MOTOR EQUIPMENT UTILIZATION RECORD						
DATE (YYMMDD) TYPE OF EQUIPMENT	Rivers		REGISTRATION NO./SERIAL NO.			ADMINISTRATION NO.
Nov 15 2001 90 Dodge Ram	Van	ner em	2B5WB35Z0MK445431 DB-633			52222 gas card #
ORGANIZATION NAME	ACTION	TI	IME	MILES	HOURS	FUEL OIL
1ST OPERATOR (Last Name, First, M.I.)	IN	16		42,422	3, 4,858,000	REPORT TO (Last Name, First, M.I.)
SPECHT KORELTO	OUT	In b	THING	42,000		DISPATCHER'S SIGNATURE
Short har	TOTAL			422	tr-tichari	Wint HILL, UA
P MON MON First, M.I.	IN					REPORT TO (Last Name, Eirst, M.I.)
OPERATOR'S SIGNATURE	OUT		AL OIL		S. James Will	DISPATCHER'S SHENATURE
*4. Time Indicate time metho nences 5 m	TOTAL	136 36	pont		Steel mid code	Doruly Brier
3D OPERATOR (Last Name, First, M.I.)	IN				REPORT TO (Last Name, First, M.I.)	
OPERATOR'S SIGNATURE	OUT				3. Dispatritor	DISPATCHER'S SIGNATURE
	TOTAL				T tobasa ta	DUIDLANG COMPANY OF THE LOCAL
4TH OPERATOR (Last Name, First, M.I.)	IN	0 800	0.116		darus) opensu	REPORT TO (Last Name, First, M.I.)
OPERATOR'S SIGNATURE	OUT					DISPATCHER'S SIGNATURE
OF ETHATOMOSISHAN ONE	TOTAL	141 1191	OH III			Desired Congress
West of the second seco	TIME		RELEASED BY		BY	REMARKS
DESTINATION	ARRIVE	DEPAR	Т	Signature)	REWARKS
IN MY HILL FARMS, VA	og sombo	1000				Vehicle is being Maintained at
TO Fort Monmouth 1010	1600	1615	-		CONTRACTOR	Maintained at
3. Fitness Center	1630	164:	5			the Motor Poole
* Alotor Poole	1700					
5.						
TO 6.						
To This vehick	e h	ave	be	en in	specte	Lor fransport
TO is being Us	d	QU	00	daily	basis	For Fransport
9. For the Mati	orea		64	ards a	Nd is	being
10. Maintained by	He	14	20/	OF POO	Le.	J
TO 11.						
то						
12.						
TO 13.						
то						
14.						
15.						
то						

VEHICLE MAINTENANCE HISTORY 90 Dodge Ram Van 2B5WB35Z0MK445431

Operation Inspection List (to be completed mileage maintenance inspection)	at every
Accident Damage	DATE 25 MO
Other Damage	
Leaks	
Tires, Tracks wheel	
Fuel, oil, coolant	
Battery	
Horn, Safety Devices	
Lights, Reflectors Glass	
Instruments	
Windshield wipers	
Communication equipment	
Cargo, mounted equipment	
Steering	
Belts/pulleys	
Brakes	
Power unit/engine	
Accident Report Form	

This vehicle have been turned of over to the motor poote, 25 Mov. of For transportation For the Troops. For transportation with the maintenance They will keep up with the maintenance by the MRUR Schedule.

MAINTENANCE TO BE COMPLETED EVERY 5000 MILES

Oil	
Oil Filter	
Lube	
Front Diff	
Rear Diff	
Transfer Case	
Transmission Fluid	5,
Air Filter	
Power Steering Fluid	
Brake Fluid	
Windshield Washer Fluid	
Anti Freeze/Coolant	
Battery	
Wash F&R Windows	
Vacuum interior	
Tire Pressure	

Received By 25 Nov. 01
Thomas I June

SCHEDULED MAINTENANCE PER MILEAGE OF VEHICLE 5000	
Rotate tires	
Lubricate steering linkage	
suspension	
drive shaft U-joint if equipped	
with grease fittings Inspect exhaust system for leaks	
damage or loose parts	
Remove any foreign material trapped	
by exhaust system shielding.	
Lubricate rear drive shaft double cardan jo	int centering
ball	
10,000	
10,000 Change engine oil	
Replace oil filter	
mepando del rerose	
15,000	
Change engine oil	
Replace Oil filter	
Inspect engine cooling system,	
hoses, and clamps Rotate tires	
Inspect and lubricate automatic	
transmission shift leakage	
Lubricate steering linkage	
suspension	
Drive shaft U-joint is equipped	
with grease fittings Inspect exhaust system for leaks,	
damage or loose parts	
Remove any foreign material trapped	
by exhaust system	
Lubricate rear drive shaft double	
cardan joint centering ball.	
20,000	
Change engine oil	
Replace oil filter	
25,000	
Change engine oil	
Replace oil filter	
Inspect engine cooling system,	

Check coolant strength every 15,000 miles or 12 months Rotate tires Inspect and lubricate automatic transmission shift leakage Lubricate steering linkage suspension Drive shaft U-joint if equipped with grease fittings Inspect exhaust system for leaks, damage to loose parts Remove any foreign material trapped by exhaust system shielding 30,000 Change engine oil Replace oil filter Inspect engine cooling system, hoses, and clamps Check coolant strength every 15,000 miles or 12 months Rotate tires Inspect and lubricate automatic transmission shift leakage Lubricate steering linkage suspension Drive shaft U-joint if equipped with grease fittings Inspect exhaust system for leaks, damage to loose parts Remove any foreign material trapped by exhaust system shielding 35,000 Change engine oil Replace oil filter Inspect engine cooling system, hoses, and clamps Check coolant strength every 15,000 miles or 12 months Rotate tires Inspect and lubricate automatic transmission shift leakage Lubricate steering linkage suspension Drive shaft U-joint if equipped with grease fittings

Inspect exhaust system for leaks, damage to loose parts Remove any foreign material trapped by exhaust system shielding	
Change engine oil Replace oil filter Inspect engine cooling system, hoses, and clamps Check coolant strength every 15,000 miles or 12 months Rotate tires Inspect and lubricate automatic transmission shift leakage Lubricate steering linkage suspension Drive shaft U-joint if equipped with grease fittings Inspect exhaust system for leaks, damage to loose parts Remove any foreign material trapped	
45,000 Change engine oil Replace oil filter Inspect engine cooling system, hoses, and clamps Check coolant strength every 15,000 miles or 12 months Rotate tires Inspect and lubricate automatic transmission shift leakage Lubricate steering linkage suspension Drive shaft U-joint if equipped with grease fittings Inspect exhaust system for leaks, damage to loose parts Remove any foreign material trapped by exhaust system shielding	
50,000 Change engine oil	

inspect engine cooling system,		
hoses, and clamps		
Check coolant strength every 15,000		
miles or 12 months		
Rotate tires		
Inspect and lubricate automatic		-
transmission shift leakage		
Lubricate steering linkage		
suspension		
Drive shaft U-joint if equipped		
with grease fittings		
Inspect exhaust system for leaks,		
damage to loose parts		
Remove any foreign material trapped		
by exhaust system shielding		
55,000		
Change engine oil		
Replace oil filter		
Inspect engine cooling system,		
hoses, and clamps		
Check coolant strength every 15,000		
miles or 12 months		
Rotate tires		
Inspect and lubricate automatic		
transmission shift leakage		
Lubricate steering linkage		
suspension		
Drive shaft U-joint if equipped		
with grease fittings		
Inspect exhaust system for leaks,		
damage to loose parts		
Remove any foreign material trapped		
by exhaust system shielding		
•		
60,000		
Change engine oil		
Replace oil filter		
Inspect engine cooling system,		
hoses, and clamps		
Check coolant strength every 15,000		
miles or 12 months		
Rotate tires		
Inspect and lubricate automatic		
transmission shift leakage		
Lubricate steering linkage		
suspension		

Drive shaft U-joint if equipped	
with grease fittings	
Inspect exhaust system for leaks,	
damage to loose parts	
Remove any foreign material trapped	
by exhaust system shielding	